



REFERENCE NOTES:

- ① MOUNT ABOVE CEILING FOR PROJECTOR
- ② MOUNT 6" BELOW CEILING FOR TV
- ③ PROVIDE CONNECTION TO FIRE ALARM PANEL. DOORS ARE TO CLOSE WHEN FIRE ALARM IS IN ALARM MODE.
- ④ CABLE TRAY. CABLOFIL CF105 SERIES WIDTH AS NOTED ON DRAWING. CABLE TRAY TO BE CENTER HUNG.
- ⑤ CABLE TRAY. CABLOFIL CF150 SERIES WIDTH AS INDICATED ON DRAWING. CABLE TRAY TO BE CENTER HUNG.
- ⑥ HILTI FIRE STOP SLEEVES (1) #CP653-4
- ⑦ HILTI FIRESTOP SLEEVES (2) #CP653-4
- ⑧ HILTI FIRESTOP GANGPLATE 16" WITH (2) GANGPLATES #CFS-SL & (3) CP653-4
- ⑨ (2) HILTI FIRESTOP HITI FIRESTOP GANGPLATE (2) GANGPLATES #CFS-SL & (4) CP653-4 (EACH) AND (1) HILTI FIRESTOP GANGPLATE 16" WITH (2) GANGPLATES #CFS-SL & (3) CP653-4 OF 11 PATHS)
- ⑩ (3) HILTI FIRESTOP GANGPLATES 24" WITH (2) #CFS-SL & (4) CP653-4 (EACH) AND (1) HILTI FIRESTOP GANGPLATE 16" WITH (2) GANGPLATES #CFS-SL & (3) CP653-4 (TOTAL 11 PATHS). PENETRATE FLOOR BEHIND RACK OF 5 FLOOR. SEE DETAIL 3/E420.

UNDER PLATFORM

FIRE ALARM MONITOR MODULE TO MONITOR HOOD SUPPRESSION SYSTEM

INTERCOM ADMIN PHONE

INTERCOM ADMIN PHONE