	KNG Series Mobile Radios								
Line No.	Product Name	Product Description	Est.Qty	UOM	State Price				
1	KNG-M150LP	Mobile, Dash Mount, P25, Digital/Analog, 136-174MHz, 5000 channels, 50W, Integrated GPS	1	Each					
2	KNG-M150LP-RCP	KNG Series Mobile Radio, Dash Mount, P25, Digital/Analog, 136-174MHz, Integrated GPS, 5000 channels, 50W, Includes Dual Remote-Control Port	1	Each					
	KNG-WIJOEF-NGF	Mobile, Trunk Mount, P25, Digital/Analog, 136-174 MHz, 5000 channels, 50W, Integrated GPS, includes dual		Lacii					
3	KNG-M150LPR	remote port	1	Each					
4	KNG-M150HP	Mobile, Dash Mount, P25, Digital/Analog, 136-174MHz ,5000 channels, 110W, Integrated GPS, includes dual remote port	1	Each					
5	KNG-M150HPR	Mobile, Trunk Mount, P25, Digital/Analog ,136-174MHz, 5000 channels, 110W, Integrated GPS, includes dual remote port	1	Each					
6	KNG-M400	Mobile, Dash Mount, P25, Digital/Analog, 380-470 MHz, 5000 channels, 50W, Integrated GPS, includes dual remote port	1	Each					
		Mobile, Trunk Mount, P25, Digital/Analog, 380-470 MHz, 5000 channels, 50W, Integrated GPS, includes dual							
7	KNG-M400R	remote port Mobile, Dash Mount, P25, Digital/Analog, 763-870 MHz, 5000 channels, 30/35W, Integrated GPS, includes	1	Each					
8	KNG-M800	dual remote port Mobile, Trunk Mount, P25, Digital/Analog, 763-870 MHz, 5000 channels, 30/35W, Integrated GPS, includes	1	Each					
9	KNG-M800R	dual remote port	1	Each					
Options for KNG Series Mobile Radios Software Options/Factory Install									
10	KZA0569	Factory Install, P25 9600 Baud Trunking	1	Each					
11	KZA0576	Factory Install DES / AES Encryption	1	Each					
12	KZA0580	Factory Install, P25 Over the Air Rekeying (OTAR) " Must have KZA0576"	1	Each					
13	KZA0583	Factory Install, Vote Scan	1	Each					
14	KZA0592	Factory Install, OTAP, Trunking, "Must have KZA0569"	1	Each					
15	KZA0594	Factory Install, TDMA "Must have KZA0569".	1	Each					
16	KZA0596	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569"	1	Each					
17 18	KZA0614	Factory Install, Kit, Nameplate	1	Each					
19	KZA0735 KZA0903	Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order)	1	Each Each					
19	KZA0903	Extended Warranty		EdCII					
20	LFW0036	Extend warranty 36 months. (Radio Only)	1	Each					
21	LFW0036EM	Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO.	1	Each					
		Antennas							
22	KAA0834	Antenna, GPS w/17 ft. cable	1	Each					
		Antenna, Combo Mount NMO/GPS, includes 17 ft. cables w/male connector (GPS) and N-Type male plug							
23	KAA0835	connector (radio).	1	Each					
24	MAGMT-NTYPE	Magnetic Mount Base 17 ft Cable N Type	1	Each					
25	MAGMT-UHF	Magnetic mount base for mobile antenna, includes 17 ft cable & UHF (PL259) style connector.	1	Each					
26 27	MWU4002S MWV1360S	UHF mobile antenna, 380-520MHz, for NMO mount, 2.0 dB gain VHF Mobile Antenna, 136-174 MHz, compatible with NMO mount, unity gain	1	Each Each					
28	MWV800	Mobile Antenna, 763-870 MHZ	1	Each					
29	MWV800NGP	Antenna Mobile, 806-866MHz, MUF8003NGP (S)No Ground Plane Required	1	Each					
30	MWV800STB	Antenna, OMNI, NMO, 698-960 MHz /1700-2700 MHz, 3.5 dbi, 100 W for KNG-M	1	Each					
31	NMO-NTYPE	Fixed Antenna Mount NMO w/ Type N Connector with 17 ft. cable	1	Each					
32	NMO-NTYPE-L	Mount, Antenna, Perm Hole 3/4, NMOKHFUD, vehicle roof mount antenna installation hardware kit. The center pin is to be removable to function as a standard or high-frequency mount.	1	Each					
32	THE CONTRACTOR	Microphones and Speakers		Luon					
33	BKR0261	Speaker, External, 20W, 4 Ohm, w/mounting bracket (replaces part KAA0261)	1	Each					
34	KAA0276S	Standard Handheld Microphone with Straight connector	1	Each					
35	KAA0290S	Handheld Programming Smart Microphone with straight connector (Standard)	1	Each					
36	KAA0647	Auxillary / Speaker Cable Assembly	1	Each					
37	KAA07110	Handset, Radio Telephone	1	Each					
	Lagy ov	Programming Accessories							
38	ASK-CK	Advanced Security Key (ASK) Child Key, Flash Drive (system key form required)	1	Each					
39	ASK-MK BKR0733	Bundle, Master Key (system key form required) Software, Radio Editor, BKR0733, current version. x.x.xx, CD, BKR/KNG	1	Each					
40	BKR0733-USB	Software, Radio Editor, BKR0733, current version. x.x.xx, USB Drive, BKR/KNG	1	Each Each					
41	KAA0660	Remote Control Head Plug & Play (Comes with KAA0638 Install Kit)	1	Each					
43	KAA0670	Hand Held Control Head (HCH)	1	Each					
		Cables & Kits							
44	KAA0587A	Cable Key Encryption KNG to KVL3000/4000	1	Each					
45	KAA0609	Cable Kit, Service	1	Each					
46	KAA0609A	Cable Kit, Service, Viavi/Aeroflex	1	Each					
47	KAA0613	Cable Assembly, KAA0276 Extension, 15 ft.	1	Each					
48	KAA0614	Kit, Nameplate	1	Each					
49	KAA0616	Cable, Interface, FireCom	1	Each					
50	KAA0622	Cable, Interface, Motorcycle, SetCom	1	Each					
51	KAA0628	Cradle, Desktop, HCH/RCH Interface	1	Each					
52	KAA0630	Kit Install, Bracket & Power Cord Mobile Dash and Remote (Replacement or Spare)	1	Each					
53	KAA0631	Kit, Mobile, Mounting Adaptor to Kenwood	1	Each					

Attachment B - Price Sheet BK Technologies Mobile Radios

54 KAAO6 55 KAAO6 56 KAAO6 57 KAAO6 58 KAAO6	1633				
56 KAA06	3033	Kit, Install, 12 AWG, Dash Mount	1	Each	
57 KAA06	0634	Cable Assembly, 30 inch remote mount interface	1	Each	
57 KAA06	0635	Cable Assembly, Remote Mount 8 ft	1	Each	
	0636	Cable Assembly, Remote Mount 17 ft	1	Each	
		Cable Assembly, Remote Mount 25 ft	1	Each	
	0637-2	Cable Assembly, Remote, 35 ft	1	Each	
60 KAA06		Kit Install for KAA0660 (Replacement or Spare) remote control head.	1	Each	
			1		
61 KAA06		Kit Install KAA0670 HCH Trunk Mount "Remote Interface Box"		Each	
62 KAA06		Kit, Install, Cab Mount, KAA0670 HCH	1	Each	
63 KAA06		Cable Kit, KNG-M to MSAT, Noise Inhibit	1	Each	
64 KAA06	0642	Kit, Interface KNG-M/RCH for KAA0628	1	Each	
65 KAA06	0647	Cable Assembly, ACC, 25 pin w/audio Jack	1	Each	
66 KAA06	0647A	Cable Assy, ACC, 25 pin w/audio Jack	1	Each	
67 KAA06	0656	Cable, RCH Extension, 300ft	1	Each	
68 KAA06	0656-100	Cable, RCH Extension, 100ft	1	Each	
69 KAA06	0659	Multi Splitter, Interface HCH/RCH	1	Each	
70 KAA06		Control Head Cover	1	Each	
71 KAA06		Kit, Strain Relief, KAA0290/0276 Microphone Cord	1	Each	
72 KAA07		Legacy / KNG Cloning Cable Portable & Mobile D/G Series, backwards compatible.	1	Each	
73 KAA07		Cable, Authentication, Key Loader	1	Each	
74 KAA07		KNG Programming Cable USB	1	Each	
75 KAA07	07110	Handset, Radio Telephone	1	Each	
76 KAA07	07110-CH	Cradle Housing, Replacement, KAA07110	1	Each	<u> </u>
77 KAA07	0720	Firmware Programming Extension Microphone Cable w/ Switch	1	Each	
78 KAAM	MSAT	MSAT to KNG Mobile Interface Cable	1	Each	
79 NS153		Filter, Line, 15A, Chassis Mount	1	Each	
	-		1	Each	
		VNO Corios Dono Chatiana		Lacii	<u>l</u>
		KNG Series Base Stations			
					State
Line No. P	Product Name	Product Description	Est.Qty	UOM	Price
80 KNG-E	-B150LP	Base Station, P25, 136-174 MHz, 5000Ch, 50W, Integrated GPS.	1	Each	
	-B150HP	Base Station, P25 Digital VHF 136-174MHz, 5000 Channels, High-Power 110 Watts, Integrated GPS.	1	Each	
82 KNG-E		Base, Station, Digital UHF 380-470MHz, 5000 Channels, 50 Watts, Integrated GPS.	1	Each	
83 KNG-E	-B800	Base, Station, Digital 763-870 MHz, 5000 Channels, 30/35 Watts, Integrated GPS.	1	Each	
		Options for KNG Series Base Stations			
		Software Options/Factory Install			1
84 KZA05		Factory Install, P25 9600 Baud Trunking	1	Each	
85 KZA05	0576	Factory Install DES / AES Encryption	1	Each	
86 KZA05	0580	Factory Install, P25 Over the Air Rekeying (OTAR) " Must have KZA0576"	1	Each	
87 KZA05	0583	Factory Install, Vote Scan	1	Each	
88 KZA05	0592	Factory Install, Over-the-air programming (OATP), Trunking, "Must have KZA0569"	4	Each	
89 KZA05	0594	Factory Install, TDMA, "Must have KZA0569"	1	Each	
		i actory install, rolvin, widst have NZA0009	1	Each	
	0596	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569"			
90 KZA05		Factory Install, Radio Authentication "Must have KZA0576 & KZA0569"	1	Each Each	
90 KZA05 91 KZA06	0615	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse	1 1 1	Each Each Each	
90 KZAO5 91 KZAO6 92 KZAO6	0615 0616	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface	1 1 1 1	Each Each Each Each	
90 KZAOS 91 KZAOS 92 KZAOS 93 KZAOS	0615 0616 0735	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB	1 1 1 1	Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOE 94 KZAOE	0615 0616 0735 0903	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order)	1 1 1 1 1	Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAO7 94 KZAOE 95 KZAO	0615 0616 0735 0903 2027	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS	1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOE 94 KZAOE	0615 0616 0735 0903 2027	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software	1 1 1 1 1	Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE	0615 0616 0735 0903 2027 2028	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty	1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE	0615 0616 0735 0903 2027 2028	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only)	1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE	0615 0616 0735 0903 2027 2028	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO.	1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE	0615 0616 0735 0903 2027 2028 0036 0036EB	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas	1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAO 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE	0615 0616 0735 0903 2027 2028 0036 0036EB	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable	1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOT 94 KZAOE 95 KZAOC 96 KZAOC 97 LFWOO 98 LFWOO 99 MAGN 100 MAGN	0615 0616 0735 0903 2027 2028 0036 0036EB iMT-NTYPE	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable	1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOT 94 KZAOE 95 KZAOC 96 KZAOC 97 LFWOO 98 LFWOO 99 MAGN 100 MAGN	0615 0616 0735 0903 2027 2028 0036 0036EB	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable	1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 92 KZAOE 93 KZAOT 94 KZAOE 95 KZAOC 96 KZAOC 97 LFWOO 98 LFWOO 99 MAGN 100 MAGN	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable	1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 99 MAGM 100 MAGM 101 MWU4 102 MWV8	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz	1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 100 MAGN 101 MWU4 102 MWV8	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extended warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ	1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 100 MAGN 101 MWU4 102 MWV8	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S /800 /1360S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extended warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz	1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAZE 96 KZAZE 97 LFWOE 98 LFWOE 100 MAGM 101 MWU4 102 MWV8 103 MWV1	0615 0616 0735 0903 2027 2028 0036 0036EB MIT-NTYPE MIT-UHF J4002S J800 J1360S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extended warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHZ Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261)	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZACE 96 KZACE 97 LFWOE 98 LFWOE 100 MAGN 101 MWU4 102 MWV8 103 MWV1	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S J800 J1360S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOC 96 KZAOC 97 LFWOO 98 LFWOO 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 105 KAAOE 106 KAAOE	0615 0616 0735 0903 2027 2028 0036 0036EB MIT-NTYPE MIMT-UHF J4002S //800 //1360S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 105 KAAOE 106 KAAOE 107 KAAOE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S //800 //1360S 0261 0258 0276S 0290S	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard)	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOT 94 KZAOE 95 KZAOC 96 KZAOC 97 LFWOO 98 LFWOO 100 MAGM 101 MWU4 102 MWV8 103 MWV1 104 BKROC 105 KAAOC 107 KAAOC 108 KAAOC	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S /800 //1360S 0261 0258 0276S 0290S 0647	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 105 KAAOE 106 KAAOE 107 KAAOE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S /800 //1360S 0261 0258 0276S 0290S 0647	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assy, ACC, 25 pin w/audio Jack	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAZO 96 KZAZO 97 LFWOO 98 LFWOO 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROZ 106 KAAOZ 107 KAAOZ 108 KAAOE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S /800 /1360S 0261 0258 0276S 0290S 0647 0647A	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extended warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assy, ACC, 25 pin w/audio Jack Programming Accessories		Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 99 MAGN 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 106 KAAOE 107 KAAOE 108 KAAOE 109 KAAOE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S /800 /1360S 0261 0258 0276S 0290S 0647 0647A	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extended warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assy, ACC, 25 pin w/audio Jack Programming Accessories Advanced Security Key (ASK) Child Key, Flash Drive (system key form required)	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 99 MAGN 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 106 KAAOE 107 KAAOE 108 KAAOE 109 KAAOE 110 ASK-C 111 ASK-M	0615 0616 0735 0903 2027 2028 0036 0036EB 0036EB MT-NTYPE MT-UHF J4002S /800 /1360S 0261 0258 0276S 0290S 0647 0647A	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ UHF Mobile Antenna, 136-174 MHz Wicrophones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assembly, ACC, 25 pin w/audio Jack Programming Accessories Advanced Security Key (ASK) Child Key, Flash Drive (system key form required) Bundle, Master Key (system key form required)		Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 99 MAGN 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 106 KAAOE 107 KAAOE 109 KAAOE 110 ASK-C 111 ASK-N 112 BKROE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF J4002S //800 //1360S 0261 0258 0276S 0290S 0647 0647A	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Wicrophones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assembly, ACC, 25 pin w/audio Jack Programming Accessories Advanced Security Key (ASK) Child Key, Flash Drive (system key form required) Bundle, Master Key (system key form required) Software, Radio Editor, BKR0733, current version. x.x.xx, CD		Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAO7 94 KZAOE 95 KZACC 96 KZACC 97 LFWOO 98 LFWOO 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKRO2 106 KAAO2 107 KAAO2 108 KAAOE 109 KAAOE 110 ASK-C 111 ASK-N 112 BKRO2	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF 04002S 0800 041360S 0261 0258 0276S 0290S 0647 0647A 0CK MK 0733 0733-USB	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Microphones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assembly, ACC, 25 pin w/audio Jack Programming Accessories Advanced Security Key (ASK) Child Key, Flash Drive (system key form required) Software, Radio Editor, BKR0733, current version. x.x.xx, USB Driv	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Each Each Each Each Each Each Each Each	
90 KZAOE 91 KZAOE 91 KZAOE 92 KZAOE 93 KZAOF 94 KZAOE 95 KZAOE 96 KZAOE 97 LFWOE 98 LFWOE 99 MAGN 100 MAGN 101 MWU4 102 MWV8 103 MWV1 104 BKROE 106 KAAOE 107 KAAOE 109 KAAOE 109 KAAOE 110 ASK-C 111 ASK-N 112 BKROE	0615 0616 0735 0903 2027 2028 0036 0036EB MT-NTYPE MT-UHF 04002S 0800 041360S 0261 0258 0276S 0290S 0647 0647A 0647A 0647A 0733 0733-USB 0587A	Factory Install, Radio Authentication "Must have KZA0576 & KZA0569" Interface Board, Audio Headse Factory Install, Remote Interface Factory Install, Remote Interface Factory Install, Advance Security Key Token, USB Factory Programming (code plug/frequencies must be submitted with order) Factory Install, Tone Termination Panel, IDA, Requires LAA2027PS Factory Install, Tone Termination Panel, Vega, Includes Program Cable & Software Extended Warranty Extend warranty 36 months. (Radio Only) Extend warranty 36 months, Radio Only, In-warranty extension. Serial Number must be provided on PO. Antennas Mount, Mag, N-Type, Male 17 ft Cable Mount, Mag, UHFM, 17 ft cable UHF Mobile Antenna, 380-520 MHz Mobile Antenna, 763-870 MHZ VHF Mobile Antenna, 136-174 MHz Wicrophones and Speakers Speaker, External, 20 Watts, 4 Ohm, w/mounting bracket (replaces part KAA0261) Microphone, Desktop Standard Handheld Microphone with Straight connector Handheld Programming Smart Microphone with straight connector (Standard) Cable Assembly, ACC, 25 pin w/audio Jack Cable Assembly, ACC, 25 pin w/audio Jack Programming Accessories Advanced Security Key (ASK) Child Key, Flash Drive (system key form required) Bundle, Master Key (system key form required) Software, Radio Editor, BKR0733, current version. x.x.xx, CD		Each Each Each Each Each Each Each Each	

Attachment B - Price Sheet BK Technologies Mobile Radios

116	KAA0705	Cable, Authentication, Key Loader	1	Each			
117	KAA0710	KNG Programming Cable USB	1	Each			
Accessories							
118	KAA0158-V2	Power Supply, Desktop, 12Vdc, 30A-dc, 110-AC, ICT12-30	1	Each			
119	KAA0612	Kit, 19 inch Rackmount	1	Each			
120	KAA0615	Kit, Audio Interface box for Headset and Foot PTT, Does not include headset	1	Each			
121	KAA0618	Foot Switch, PTT, Heavy duty, "requires KZA0615"	1	Each			
122	KAA0619	Cable assy, Dual Microphone Extension	1	Each			
123	KAA0628	Cradle, Desktop, HCH/RCH Interface	1	Each			
124	KAA0629	Kit, RCH Expansion Splitter Box	1	Each			
125	KAA0659	Multi Splitter, Interface HCH/RCH	1	Each			
		InteropONE - A La Carte					
126	InteropONEsvc	InteropONE commercial account - Required for A La Carte, Bundling, & Enterprise orders.	1	Each			
		InteropONE, Primary User, Subscriber has Primary User features. 1-Year Subscription. Includes InteropONEsvc					
127	InteropONEsvc-primary	account.	1	Each			
		InteropONE Standard User, Subscriber has Standard User features. 1-Year Subscription. Includes InteropONEsvc					
128	InteropONEsvc-standard	account.	1	Each			
129	InteropONEsvc-guest	InteropONE Service, Pass for one Guest User for a singular incident. Includes InteropONEsvc account.	1	Each			
		InteropONE - Bundle Options		1			
		InteropONE bundle consisting of 2 Primary Users, 5 Standard Users, and 100 Guest Passes. One Year					
130	InteropONEsvc-Bundle1	Subscription. Includes InteropONEsvc account.	1	Each			
424		InteropONE bundle consisting of 2 Primary Users, 10 Standard Users, and 200 Guest Passes. One Year	4				
131	InteropONEsvc-Bundle2	Subscription. Includes InteropONEsvc account. InteropONE bundle consisting of 3 Primary Users, 5 Standard Users, and 150 Guest Passes. One Year	1	Each			
132	InteropONEsvc-Bundle3	Subscription. Includes InteropONEsvc account.	1	Each			
132	InteroportEsve-Bundles	InteropONE bundle consisting of 3 Primary Users, 10 Standard Users, and 300 Guest Passes. One Year		Lacii			
133	InteropONEsvc-Bundle4	Subscription. Includes InteropONEsvc account.	1	Each			
100	intereportation bandle i	InteropONE bundle consisting of 6 Primary Users, 5 Standard Users, and 300 Guest Passes. One Year		20011			
134	InteropONEsvc-Bundle5	Subscription. Includes InteropONEsvc account.	1	Each			
		InteropONE bundle consisting of 6 Primary Users, 10 Standard Users, and 600 Guest Passes. One Year					
135	InteropONEsvc-Bundle6	Subscription. Includes InteropONEsvc account.	1	Each			
		InteropONE - Enterprise Options					
		InteropONE Enterprise tier consisting of 25 maximum user seats. A user seat can be filled by a Primary User,					
136	InteropONEsvc-E25	Standard User, or Guest User. One Year Subscription. Includes InteropONEsvc account.	1	Each			
		InteropONE Enterprise tier consisting of 50 maximum user seats. A user seat can be filled by a Primary User,					
137	InteropONEsvc-E50	Standard User, or Guest User. One Year Subscription. Includes InteropONEsvc account.	1	Each	igsquare		
		InteropONE Enterprise tier consisting of 100 maximum user seats. A user seat can be filled by a Primary User,					
138	InteropONEsvc-E100	Standard User, or Guest User. One Year Subscription. Includes InteropONEsvc account.	1	Each	\longmapsto		
420		InteropONE Enterprise tier consisting of 250 maximum user seats. A user seat can be filled by a Primary User,	4				
139	InteropONEsvc-E250	Standard User, or Guest User. One Year Subscription. Includes InteropONEsvc account.	1	Each			
140	Interes ONEsus FECO	InteropONE service Enterprise tier consisting of 500 maximum user seats. A user seat can be filled by a Primary	1	Foob			
140	InteropONEsvc-E500	User, Standard User, or Guest User. One Year Subscription. Includes InteropONEsvc account.	1	Each	<u> </u>		